




REPAIR OF FLEXIBLE BASE PAVEMENT








## NOTE:

- EXPOSE 15" OF REINFORCING STEEL AT PROPOSED SAWED JOINT. IF NO REINFORCING STEEL EXISTS, USE HORIZONTAL DOWELS.
  HORIZONTAL DOWELS SHALL BE # 6 BARS, 24" LONG, 24" C -C, DRILLED AND EMBEDDED 8" INTO THE CENTER OF THE EXISTING SLAB. WITH "PO ROC" OR EQUAL.
- 2. IF REINFORCED CONCRETE IS OVERLAYED WITH ASPHALT, REPLACE WITH 2" MIN HMAC SURFACING.
- 3. CENTER REINFORCING IN SLAB THICKNESS.





PAVEMENT REPAIR DETAILS



PROVIDENT CONSULTING, INC.

1200 WEST 11TH ST.

HOUSTON, TEXAS 77008
(713)802-1019